



ROC SYSTEM

QUESTIONS AND ANSWERS

Q: How much Flocculent is needed to treat my water?	A: The amount of Flocculent required will vary from installation to installation. HPI Processes provides laboratory testing services at no charge to determine application rates. In general, application rates range from to 1/2 lb. to 1 lb. of Flocculent per 300-500 gallons of wastewater.
Q: How much filter media will be needed?	A: Again usage will vary, but a good rule of thumb is 20 linear feet per 1,000 gallons of wastewater.
Q: Will I need any other treatment system in addition to the ROC System?	A: Most installations only require the ROC System. Some customers may want to add a polishing column such as activated carbon after the ROC System, but in most cases this is not needed. The ROC system is also available with an integrated pH adjust feature.
Q: What happens if I put too much Flocculent into the ROC System?	A: Nothing. One of the best features of the ROC System is its flexibility. Overdosing just produces more flocculent.
Q: What kind of safety precautions need to be taken when working with the ROC System?	A: Common sense is the most important safety measure when working with the ROC System. Wearing a standard dust mask is also recommended when adding the Flocculent to the hopper.
Q: How do I dispose of the sludge generated by the ROC System?	A: In most cases, the sludge is considered non-hazardous (by passing the TLCP test) and can be disposed of in an industrial non-hazardous landfill. HPI Processes will provide the TLCP testing results at no charge. Local landfill regulations sometimes vary and should be consulted.